MODEL: 50054WDG

PACKING DIAGRAM



MODEL: 50054WDG

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS FOUNTAIN SHOULD TAKE APPROXIMATELY 15 MINUTES TO ASSEMBLE.

MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

UNPACK THE FOUNTAIN

YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS: COLUMN, FOUNTAIN BODY, RESERVOIR WITH LED CLUSTER, PUMP AND TRANSFORMER.

FOUNTAIN ASSEMBLY

1. JOIN THE LIGHT CONNECTORS AND SCREW THE CAP TO THE CONNECTORS TIGHTLY TOGETHER, AND THEN PLACE THE PUMP INTO RESERVOIR.



2. FEED THE RUBBER HOSE THROUGH THE HOLE TOWARD BOTTOM OF THE FOUNTAIN BODY, AND THEN PLACE THE COLUMN ONTO TOP OF THE FOUNTAIN BODY AND TWIST THE COLUMN CLOCKWISE TO SECURE.



3. ATTACH THE PUMP TO THE RUBBER HOSE AND PLACE THE FOUNTAIN BODY WITH COLUMN ONTO TOP OF THE RESERVOIR, MAKE SURE THE PUMP POWER CORD EXITS OUT FROM THE NOTCH.



4. FILL RESERVOIR WITH 4.5 GALLONS OF WATER TO COMPLETELY SUBMERSE THE PUMP.

NOTE: DISTILLED WATER IS RECOMMENDED TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD–UP.



MODEL: 50054WDG

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

FOUNTAIN ASSEMBLY

5. JOIN CONNECTORS AT TRANSFORMER AND SCREW THE CAP TO CONNECTOR TIGHTLY TOGETHER.

6. PLUG TRANSFORMER INTO OUTLET, THEN TEST WATER RUNNING, ADJUST THE WATER VALVE ON PUMP IF NEEDED.

7. YOUR NEW FOUNTAIN IS READY FOR USE.



AVAILABLE PARTS ARE:
BULB3009 (LED CLUSTER)
PUMP1047 (PUMP)
TRANS2019 (TRANSFORMER)

TROUBLE SHOOTING:

1. IF YOUR FOUNTAIN DOES NOT WORK, CHECK PLUG AT THE SOCKET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE WALL OUTLET.

2. NEXT CHECK TO MAKE SURE THE OUTLET IS POWERED.

3. IF THE FOUNTAIN STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

SPLASHING DISCLAIMER:

SPLASHING MAY OCCUR WHEN FOUNTAIN IS INITIALLY TURNED ON. PROTECT SURROUNDING SURFACES AS NEEDED.

IMPORTANT PUMP INFORMATION:

PUMP MUST BE FULLY SUBMERSED IN WATER WHILE OPERATING.

WATER:

TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP THE USE OF DISTILLED WATER IS RECOMMENDED.

WARNING:

* ONCE A WEEK INSPECT FOUNTAIN, FLOOR AND ADJACENT WALL FOR MOISTURE BUILD–UP AND CLEAN AS NECESSARY. THIS IS ESPECIALLY IMPORTANT FOR HUMID ENVIRONMENTS.

** THIS FOUNTAIN IS RATED FOR OUTDOOR USE.

*** THIS UNIT MUST BE CONNECTED TO A SUPPLY CIRCUIT THAT IS PROTECTED BY A GROUND FAULT CIRCUIT INTERRUPTER (GFCI). THE GFCI SHOULD BE TESTED ON A ROUTINE BASIS. TO TEST THE GFCI, PUSH THE TEST BUTTON. THE GFCI SHOULD INTERRUPT POWER. PUSH THE RESET BUTTON. POWER SHOULD BE RESTORED. IF THE GFCI FAILS TO OPERATE IN THIS MANNER, THE GFCI IS DEFECTIVE.